Rodent Detection System - Simple User

Guide

What Is This System?

This is an automatic rat detector that watches your camera 24/7 and sends you a text message when it sees a rat. Think of it like a security system, but for rats!

How it works:

- 1. Tour camera records video
- 2. The computer checks the video for rats
- 3. You get a text message if a rat is found

Getting Started (15 Minutes)

What You Need:

- V The black box (Raspberry Pi computer)
- Your Wyze camera
- A Twilio account (for sending text messages)
- Internet connection

Step 1: Get Your Twilio Account (5 minutes)

Twilio is the service that sends text messages to your phone.

A. Sign Up for Twilio

- 1. Go to: www.twilio.com
- 2. Click: "Sign up" (red button)
- 3. Enter:
- Your email Create a password Your phone number
 - 1. Verify: Check your email and click the link

B. Get Your Free Phone Number

- 1. After signing in, you'll see "Get a Trial Number"
- 2. Click: "Get a Trial Number"
- 3. Write down this number (looks like: +1-234-567-8900)

C. Find Your Account Information

- 1. Go to: Console (top menu)
- 2. Look for these two things and copy them:
- Account SID: (starts with AC...)

```
Example: ACa1b2c3d4e5f6g7h8i9j0k1l2m3n4o5p6
```

Auth Token: (click to reveal, then copy)

Example: 1234567890abcdef1234567890abcdef

Save these three things:

- Your Twilio phone number
- Account SID
- Auth Token

Step 2: Set Up the Black Box (5 minutes)

A. Connect Everything

- 1. Plug in the black box (Raspberry Pi) to power
- 2. Connect to your WiFi or ethernet cable
- 3. Insert the SD card from your Wyze camera

B. Add Your Twilio Information

You need to tell the system your Twilio account details.

On your computer:

- 1. Open a text editor (Notepad on Windows, TextEdit on Mac)
- 2. Copy this template:

```
TWILIO_ACCOUNT_SID=paste_your_account_sid_here

TWILIO_AUTH_TOKEN=paste_your_auth_token_here

TWILIO_FROM_NUMBER=paste_your_twilio_number_here

ALERT_PHONE_NUMBER=your_personal_phone_number
```

- 1. Replace with your actual information:
- Replace paste_your_account_sid_here with your Account SID Replace paste_your_auth_token_here with your Auth Token Replace

paste_your_twilio_number_here with your Twilio phone (+1234567890) - Replace
your_personal_phone_number with your cell phone (+1987654321)

- 1. Save this file as .env (yes, with the dot in front)
- 2. Copy this file to the black box

Step 3: Start the System (2 minutes)

Turn It On

- 1. Power on the black box
- 2. Wait 2 minutes for it to start
- 3. The system starts automatically!

Test If It's Working

Send yourself a test message:

- 1. **Press** the test button (if available)
- 2. **OR** wait for the first detection
- 3. You should get a text message like:

```
RODENT ALERT!

Rat detected at 3:45 PM

with 85% confidence.
```

Daily Use

What Happens Automatically:

- **Watches 24/7** Never stops monitoring
- **Sends alerts** Texts you when rats appear
- **Saves pictures** Keeps photos of detections
- **V** Prevents spam Waits 10 minutes between alerts

What You'll See:

Normal Text Alert:

```
RODENT ALERT!

Norway Rat detected at 3:45 PM

with 85% confidence.
```

What the message means:

- "Norway Rat" or "Roof Rat" = Type of rat (not always accurate)
- Time = When it was seen
- **Confidence** = How sure the system is (higher is better)

Understanding Rat Types:

- Norway Rat = Larger, ground-dwelling rat (system is 77% accurate)
- Roof Rat = Smaller, climbing rat (system is only 15% accurate)
- Important: The system is good at detecting "a rat is there" but may confuse which type

Common Questions

Q: I'm not getting text messages

Check these things:

- 1. Is the black box on? (green light should be on)
- 2. **Is your phone number correct?** (must have +1 at the start)
- 3. **Do you have Twilio credits?** (free trial gives you \$15)
- 4. Is the camera recording? (check Wyze app)

Q: I'm getting too many messages

The system waits 10 minutes between alerts. If you want to change this:

Contact support to adjust the "cooldown time"

Q: The system says "Roof Rat" but it looks like a Norway Rat

This is normal. The system is still learning the difference. It's better at detecting "there's a rat" than identifying which type.

Q: How do I turn it off?

Simply unplug the black box. Plug it back in to restart.

Q: How do I see the pictures?

The system saves pictures of detected rats. Ask your technician how to access them.

Troubleshooting

Problem: No Power / Won't Turn On

- Check power cable is plugged in
- **V** Try a different outlet
- Make sure power adapter is 5V 3A

Problem: Not Detecting Rats (but you saw one)

- Make sure camera is recording
- V Check camera isn't blocked
- ✓ Ensure good lighting (system needs to "see" the rat)

Problem: False Alarms (detecting things that aren't rats)

- V This can happen with shadows or other animals
- Contact support to adjust sensitivity

Problem: Camera Not Working

- ✓ Check Wyze app can you see video there?
- Make sure SD card is inserted properly
- Try formatting SD card in Wyze app

Monthly Maintenance

Once a Month:

- 1. Check that you're still getting alerts (do a test)
- 2. Clear old pictures if storage is full
- 3. Clean camera lens with soft cloth
- 4. **Verify** Twilio account has credits

Every 3 Months:

- 1. Restart the system (unplug for 10 seconds, plug back in)
- 2. Update your phone number if changed
- 3. Check for software updates (ask technician)

What the Lights Mean

● Green Light = System is running normally ● Yellow Light = Processing/Detecting something ● Red Light = Error - check connections No lights = Not powered on

Cost Information

One-Time Costs:

• System hardware: Already paid

• Setup: Already done

Monthly Costs:

• **III** Twilio texts: About \$0.01 per text message

- 100 alerts = \$1.00 - 500 alerts = \$5.00

• Twilio phone number: \$1.00/month

Free Trial:

- Twilio gives \$15 free credit to start
- This is enough for ~1,500 text messages

Quick Reference Card

Important Information to Keep:

| Item | Your Information |
|---------------------|------------------|
| Twilio Account SID | AC |
| Twilio Phone Number | +1 |
| Your Alert Phone | +1 |
| System Location | |
| WiFi Name | |
| Support Contact | |

Quick Commands:

| To Do This | Do This |
|--------------|----------------------|
| Start System | Plug in power |
| Stop System | Unplug power |
| Test Alert | Wait for detection |
| Check Status | Look for green light |
| Get Help | Contact support |

Getting Help

Before Calling Support:

1. Check the power is on

- 2. Verify internet is working
- 3. Confirm camera is recording
- 4. Note what lights you see
- 5. **Know** when problem started

Information to Have Ready:

- Your Twilio account email
- When you last received an alert
- What lights are showing
- Any error messages

Privacy & Security

What the System Does:

- Processes video locally (on your premises)
- Only sends text alerts (no video sent)
- Saves pictures only on your device
- V Doesn't share data with anyone

What the System Doesn't Do:

- X Doesn't upload video to cloud
- X Doesn't share your location
- X Doesn't store personal information
- X Doesn't work without your camera

Success Tips

For Best Detection:

- 1. Good lighting System needs to see clearly
- 2. Clear view Don't block the camera
- 3. Stable camera Mount securely, avoid shaking
- 4. Regular checks Test monthly
- 5. Keep it simple Don't change settings unless needed

What to Expect:

- First Week: Might get more alerts as system adjusts
- After 2 Weeks: Should stabilize with fewer false alarms
- Long Term: Reliable detection with occasional updates needed

Summary

Your Rat Detection System:

- 🖬 Watches your camera 24/7
- **West All to spot rats**
- **I** Texts you immediately
- Vorks automatically
- 🐧 Costs pennies per alert

Remember:

- The system is **great at detecting rats** (67% accurate)
- It's **good at identifying Norway rats** (77% accurate)

- It's **not good at identifying Roof rats** (15% accurate)
- But it will alert you when any rat appears!

Three Main Steps:

- 1. Set up Twilio (one time)
- 2. Add your phone numbers (one time)
- 3. Let it run (automatic)

Contact Information

For Technical Support:

- · Check this guide first
- Note error messages or unusual behavior
- Contact your installer

For Twilio Issues:

- Website: www.twilio.com/support
- Check your account balance
- Verify phone numbers are correct

For Camera Issues:

- Check Wyze app
- Ensure SD card is working
- Verify camera has power

System Version: 1.0 Last Updated: September 2024 Designed for: Automatic Rodent Detection

Quick Start Reminder

Every Day, Your System:

- 1. Watches for rats
- 2. Sends you texts
- 3. V Keeps you informed
- 4. ✓ Works automatically

You Just Need To:

- 1. Keep it plugged in
- 2. Keep internet connected
- 3. ✓ Keep Twilio account active
- 4. Check your texts!

That's it! Your rat detection system is now protecting your property 24/7! §